

## Set Up Instructions


1. Select your notebook manufacturer and compatible tip(s) from the chart below.
2. Check that the selected tip fits your notebook.
3. Ensure the correct Smart Voltage Card (SVC) is inserted into the adapter slot (see example below).
4. Need help? Call **1-866-908-HELP** (4357) in the U.S. or Canada or visit [www.kensington.com](http://www.kensington.com).

Notebook Manufacturer	Compatible Tip(s)
Acer®	C, D, E, H
Asus®	E, H
Compaq®	E, H, I
Dell®	H, J
Gateway®	D, H
HP®	E, H, I
IBM®	C, L
Lenovo®	C, H, L
Sony®	G
Toshiba®	B, H



If a tip fits in your notebook but does not charge when plugged in please try the other compatible tips.

**GREEN SVC** for 17-21 VDC  
**BLUE SVC** for 14-17 VDC



The adapter is preset for 17-21 VDC. To set it for 14-17 VDC, simply eject the **GREEN SVC** already in the slot and replace with the **BLUE SVC** (included).

To eject, push on the SVC in the slot using the tip of finger and release.

900-3636-00

TAZUMADESIGN

DATE: 10/6/2009

JOB#: KENSINGTON 241

DESCRIPTION: ONYX - MIXED LABEL

CPN: 900-3618-00



BLACK

DIELINE